Klaw Products Ltd

phone: 0800 55 29 55 mobile: 027 370 6666 fax: 03 328 8946

email: sales@klawklip.co.nz postal: PO Box 7241, Christchurch

KLAWKLIP

INSTRUCTION SHEET


JOINING WIRE




Place broken wire down the side of Klaw Klip into handle and bend between klaws of Klaw Klip.



Place second wire down other side of Klaw Klip sliding wire into handle and bend between klaws of Klaw Klip.




Placing wire into handle prevents it slipping out before wire is repaired.



Strain wire as normal.

REMEMBER

- Always place left hand wire down side of Klaw Klip first.
- Then place right hand wire down beside wire nearest you as in picture 2 above.
- This prevents kinking of wire and gives the correct join as seen to the right.



Completed Join.